


Can not search device

Not search device.(IP20, IP65, Interface Module)

1. Factory reset device
2. Check if any device is already registered in another zone



Page:Can not upgrade Firmware(Can not search firmware image)

Page:Device disconnects occasionally

Page:No output from the Dongle settings screen

Page:Can not search device